



Set Up Procedures for TV

For programming assistance: 813.871.0389 or info@bigbuttonremtoes.com

1. Power on TV.
2. Press and **HOLD** [ON/OFF] and [MUTE] buttons **together** until the indicator light illuminates (3 seconds).
3. Press and **RELEASE** the [CH+] button, **repeatedly**, until the TV turns off. (Tek Pal contains more than 200 codes)
4. Press and release the [MUTE] button immediately after the TV turns off to complete set-up.
5. Power the TV on using [ON/OFF]. Tip: If the TV does not power back on, you may have pressed [CH+] after the TV turned off. Proceed with setup again, but at step 3 use [CH-] to go backwards through the codes. Your TV should turn off with just a few presses of the [CH-] button.
6. For TV only users (no cable box or satellite receiver): Test the [Vol+/-], [CH+/-], and [On/Off]. If any buttons do not function, proceed with set up again.
7. For cable box/satellite receiver users: Test [On/Off] and [Vol +/-]. If [On/OFF] or [Vol +/-] buttons do not function, proceed with set up again to find a better code. Then, proceed with additional set up procedures below.

Additional Set up Procedures for Cable/Satellite devices.

1. Program TV first using instructions above.
2. Power on TV and Cable or Satellite device.
3. Press and **HOLD** [MUTE] and then the [ON/OFF] button **together** until the indicator light illuminates (3 seconds).
4. Press and **RELEASE** the [Vol+] **repeatedly** until the cable or satellite device turns off.
5. Press and release [MUTE] immediately after the cable or satellite device turns off.
6. Power the device back on manually or using your old remote.
7. Press and **HOLD** [CH-] and then [ON/OFF] buttons **together** until the indicator light blinks three times. This step will configure the Tek Pal to change channels on the cable or satellite device.

8. If the channels do not change, proceed with setup of cable or satellite device again.
Tip: If channels do not change, you may have pressed [Vol+] after the device turned off. Proceed with setup again, but at step 3 use [Vol-] to go backwards through the codes. Your device should turn off with just a few presses of the [Vol-] button.
9. To enable Master Power: First, power on both the TV and cable or satellite device. Press and **HOLD** [MUTE] and then [On/Off] together (3 seconds) until the indicator light illuminates. Press and **RELEASE** [On/Off] three times. Press and release [MUTE].